

## **RS485 Interface:**

If you use SBC-on-board RS485 interface, you need to set appropriate state of RTS line before sending/receiving data in your software program. That means, your software program must be able to set this handshake signal.

We offer additional board that can perform auto-direction hardware function.