

Panel Computer & HMI

IB32/ IB70/ IBWW

IH70/ IH32/ IHWW

IV32/ IV70

This Quick Reference Guide explains where to download and how to enable Watchdog Utility on Winmate Panel PC & HMI.

If OS has been reinstalled, it is also required to download and install Watchdog Driver.

Watchdog Utility Reference Guide

Introduction

This Quick Reference Guide explains where to download and how to enable Watchdog Utility on Winmate Panel PC & HMI. If OS has been reinstalled, it is also required to download and install Watchdog Driver.

Quick Steps to enable Watchdog Utility on your computer:

- Install Watchdog Utility on your computer.
- Open Watchdog Utility and enable Watchdog.



- Watchdog Utility is burned-in to your OS image.
- If you cannot find Watchdog Utility, please download Winmate Watchdog Utility & Driver from Winmate Download Center or Winmate File Share.

If the operating system of your computer has been reinstalled, it is required to download and install Watchdog driver to enable Watchdog.



- Install Watchdog Driver
 - a. Uninstall the old WMWDG driver
 - b. Install a new version of WMWDG driver


Winmate Watchdog utility and driver

Motherboard			Utility	Driver
IB32/	IB70/	IBWW/	WatchDog_AP V2.0.2	Driver V2.0.0.2
IH70/	IH32/	IHWW/		
IV32/	IV70			


How to Enable Watchdog in Windows OS

To enable Watchdog, first you need to download and install Winmate Watchdog Utility and then restart the system.

1. On the right bottom side of the desktop screen, click  **triangle button** to show hidden icons.
2. Click  icon to open Watchdog utility.



3. In Watchdog utility window set countdown time and periodically feed time, or disable watchdog.



**Default setting*




*Watchdog: Enable
Watchdog countdown time: 10 min
Periodically feed time: 9min*

Watchdog Driver Installation

After the operating system on your computer has been reinstalled, you need to install Watchdog driver first to enable Watchdog function.






Installation Files

Please select the driver for the corresponding operating system.

-  WMWDG 64bit Driver Installation Guide v101
-  WMWDG Driver for Win7_32bit
-  WMWDG Driver for Win7_64bit

Win7_32bit	Windows 7/8 x86 Edition
Win7_64bit	Windows 7/8 x64 Edition


Each directory contains the following files.

 x64  devcon  install  wmwdg  wmwdg	File	Description
	Devcon.exe	Driver Application
	Install.bat	Driver Installation File
	Wmwdg.cat	Digital Signature File
	Wmwdg.inf	Driver information file
	Wmwdg.sys	WMWDG Driver


Driver Installation Procedure

Uninstall the old version

Before you start installing the new signature WMWDG driver, please uninstall the old WMWDG driver in Windows's Device Manager.




Select “**WMWDG**” under System devices and right-click it. Use **Uninstall** selection to remove the driver.






II Install the driver

- i. Type "**cmd**" in the run box.
- ii. The cmd.exe will appear in Programs
- iii. Right click on the cmd.exe and click on "Run as administrator" to start command prompt.



- iv. Change directory to driver's location, and type **install** to install the driver.



```
Administrator: C:\Windows\System32\cmd.exe
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.


C:\Windows\system32>d:
D:\>cd D:\Driver\Win7_64bit
D:\Driver\Win7_64bit>install
```

- v. When Windows Security dialog appears, select **install** to continue the installation.



When the driver is successfully installed, you can see “Drivers Updated successfully” message in the dos prompt.

And “WMWDG” device also added in the Device Manger under “System devices”.



Where to Download Watchdog Utility

To find the Drivers and SDK, please refer to the Driver CD that comes in the package or contact us. Also, you can download drivers from Winmate Download Center or Winmate File Share.

Winmate Download Center

Go to <http://www.winmate.com/> > Support > Download Center

Or follow the link:

<http://www.winmate.com/DownCenter/DownLoadCenterIndex.asp>

Winmate File Share

Go to <http://www.winmate.com/> > Support > File Share > Public Documents > Panel PC

Or follow the link: <http://www.winmate.com/FileShare.htm>



NOTE

Follow your computer's CPU model to find all necessary drivers, SDK and utilities.
